

SNOWBOARD BOOT SIZE CHART



MONDO (cm)	UK	EURO	MEN'S (US)	WOMEN'S (US)
24	5	38	6	7
24.5	5.5	39	6.5	7.5
25	6	40	7	8
25.5	6.5	40.5	7.5	8.5
26	7	41	8	9
26.5	7.5	41.5	8.5	9.5
27	8	42	9	10
27.5	8.5	42.5	9.5	10.5
28	9	43	10	11
28.5	9.5	43.5	10.5	*Unavailable
29	10	44	11	*Unavailable
29.5	10.5	44.5	11.5	*Unavailable
30	11	45	12	*Unavailable
31	12	46	13	*Unavailable
32	13	47	14	*Unavailable
33	14	48	15	*Unavailable